

Installing Java on Your PC


Installing Java

- To develop Java programs on your PC:
 - Install JDK (Java Development Kit)
 - Add the directory where JDK was installed to your system path.
 - Details follow.


Download JDK 8 at

http://www.oracle.com/technetwork/java/javase/downloads/index.html

Download JDK



Download JDK




Click on the download link for your computer.


e.g., For a 64 bit Windows system, click jdk-8u65-windows-x64.exe

Install JDK

When the download is complete, double click on the file name in your Downloads folder to install the JDK.



A Popup Message



Click Yes

The "Installation Wizard" will start.


The Installation Wizard



Click Next


Custom Setup

Select "Development Tools" (the default)



Click Next

Progress Screen




The Status message will change as installation progresses.

This could take several minutes.

Destination Folder

Don't click "Change"



Note where it will be installed

Click "Next"

Oracle Advertisement

With Progress Bar



Eventually closes

It's finished




Click "Close"

Find the JDK



- Double click on Computer
- Drill down
 - OC (C)
 - Program Files
 - Java


The Java Directory



This is the JDK directory. Double click on it, then on bin.

Javac.exe is the Java compiler

Click in this box in order show the directory path in the normal format and select it.



Copy the directory path (by pressing Control-C while it is selected.) You will need to use it in the following steps.




Add the Java compiler's directory to your system path

- On Windows your "system path" specifies where the system will look for programs.
- You need to add the directory that contains the Java compiler, javac.exe

Details on the following slides.


Open Control Panel

- Click on your computer's Start button.
- Then click on "Control Panel".




Control Panel

Click on System




System

Click on Advanced system settings




System Properties

In the Advanced tab, click on the Environment Variables button.



Environment Variables

In the System variables section, select Path and click the Edit button.



Edit System Variable "Path"




At the end of the string in the Variable value text box, type a semicolon. Then paste in the path to the Java compiler by pressing Control-V.

Variable name: Path	
Variable value: n;C:\Program Files\Java\jdk1.8.0_65\bin	Į.
OK Cancel	


Click OK

Back in Environment Variables



Click OK


Back in System Properties




Click OK

Back in Control Panel

Click here to close window



Finished



- Open a new command window to compile.
 - The command window gets the system path when you open it.
 A command window that was open before you updated the system path won't have the updated path.